



## **Instructions – Hanging System – Panel Clips**

For both Perlon cord and stainless steel cable you should feed the cord through the top block and then through the hole in the Panel Clip from the top so that the top block ends up snugly cradled in the crook of the Panel Clip. For Stainless steel rods, place the top block into the crook of the Panel Clip and screw the rod in from underneath.

Then hook the Panel Clip carefully into place on top of the panel.

### **Hanging your Artworks**

Slide the appropriate barrel up the cord or rod from the bottom and tighten at the required height with the bolt heads facing toward you. It's much easier to do this with the two lengths side by side so that the barrel heights match.

For artworks with cord on the back, just place the cord over the hook. If you are using the Small Ryman Hanger, hook it over the small bolt and discard the large one and vice versa for the Large Ryman Hanger. For maximum strength be sure to tighten both the bolt (using a screwdriver) and the grub screw (using an Allen key).

With the rods at the correct distance apart, the artwork is lifted into place so that the protruding bolt heads engage with the Ryman plate on the back of the artwork.